

## **SAFE JOB PROCEDURES 4.11**

**JOB TITLE:** PARGING APPLICATION

**DEVELOPED BY:** Stan Allon      **DATE:** March 25, 2008

**APPROVED BY:** Marilyn Paxton      **POSITION:** Stucco Manager

**DATE:** March 27/08

**REVISED BY:** Serge Piorer      **DATE:** January 13, 2016

**EQUIPMENT REQUIRED:** Mixer, hand tools, broom, hose, shovel

**MATERIAL REQUIRED:** Portland cement, Lime, sand, metal lath, 1 ½” nails

**PERSONAL PROTECTIVE EQUIPMENT:** Steel toed boots, eye protection, dust masks, gloves

### **JOB STEPS:**

1. Apply wire to areas where needed with nails eg. windows, deck plates, etc.
2. Sweep foundation to remove loose debris and dirt.
3. Always pay attention to weather conditions as wet surfaces may create a slippery surface depending on the materials you are required to walk on.
4. Make mix adding Portland cement, Lime and sand to manufacturers specifications.
5. Ensure no foreign matter enters the mix and keep hands away from the mixer until it is completely stopped.
6. Ensure the cord for the mixer doesn't pose a tripping hazard.
7. Apply parging mix to foundation using hand tools.
8. Texture the parging.
9. Clean up area when complete.
10. Wash all tools and hands when done clean up, this will remove debris and any possible contaminated materials.