

SAFE JOB PROCEDURES 4.4

JOB TITLE: TAPING APPLICATION

DEVELOPED BY: Robert Paxton **DATE:** March 27, 2008

APPROVED BY: Dan Sager **POSITION:** Safety Coordinator

DATE: April 4, 2008

REVISED BY: Kayla Dilling **DATE:** January 20, 2016

EQUIPMENT REQUIRED: Ladders, scaffold, steel planks, stilts, sawhorses, taping tools – pan, knives, mixer (drill & whip), pole sander, bazooka, super taper

MATERIAL REQUIRED: Drywall fillers, joint tape, corner bead

PERSONAL PROTECTIVE EQUIPMENT: Steel toed boots, dust masks, hard hat

JOB STEPS:

1. Benches must be fully extended to the locked position when in use. Keep bench ladders regularly scraped and washed for proper use and inspection.
2. Apply joint tape and corner beads throughout house.
3. Coat all joints and beads.
4. Sand all joints and beads wearing dust masks.
5. Coat all joints and beads again.
6. Sand all joints and beads again wearing dust masks.
7. Apply finish coat.
8. When setting scaffold, all safety braces must be installed correctly and planks set safely and properly on scaffold. (planks are 12 to 14” wide).
9. Scaffold must be red tagged at the end of each day to prevent others from climbing on it.
10. All tools and hands must be washed thoroughly to remove debris and possible contaminated materials.
11. Do not eat any foods with taping filler on hands as it could be contaminated and should not be digested.
12. Eye wash bottles are strongly suggested for tapers due to the amount of dust produced by this scope of work.